


# Scale-Link™ Wireless

The industry standard take-off tool for entering linear measurements from your blueprints, maps, or plans into any Windows program. Just roll the scaler wheel along your print, then click to instantly transfer the measurement into your program. Scale-Link Wireless contains everything you need to get started. The included PlanWheel can be used remotely in the field or interfaced with your PC at distances of up to 25 feet!




Select units of readout  
(inches, feet, yards, meters, etc.)

Zero the count  
and length

Click here to  
transfer length from  
PlanWheel WL into  
software program

Transfer count from  
PlanWheel WL into  
software program



The Ready Connect™ window indicates readout  
from the PlanWheel WL™.

Change user defined  
scales, adder, etc.

Select scale factors

- Architectural, Engineering, Map, and Metric
- 111 Built-in
- Thousands of available user-defined
- Create any custom scale with auto-scale feature



## Scale-Link Wireless Includes:

- PlanWheel WL™ Scaler
- Ready Connect™ Software
- Charging Cradle w/ USB Cable
- Protective Case
- One Year Warranty
- User Manual
- Rechargeable Batteries (2AAA)

## Scale-Link is specially suited for:

- All Windows construction estimating software
- Excel®, Quatro Pro®, Lotus 1-2-3® and other spreadsheets
- Access®, dBase®, Paradox®, Foxpro®, and other databases

## System Requirements

- Windows® Compatible Computer
- CD-ROM Drive
- USB Port

Scale-Link works with all Windows® operating systems.