


# Scale-Link™ USB2

The industry standard take-off tool for entering linear measurements from your blueprints, maps, or plans into any Windows program. Just roll the scaler wheel along your print, then click to instantly transfer the measurement into your program. Scale-Link includes the scaler wheel, connecting cable and transfer software.




Select units of readout  
(inches, feet, yards, meters, etc.)

Change user defined  
scales, adder, etc.

Zero the count  
and length

Click here to  
transfer length from  
PlanWheel XLU2 into  
software program

Transfer count from  
PlanWheel XLU2 into  
software program



Select scale factors  
(architectural,  
engineering,  
map, metric)

The Ready Connect™ window indicates readout from the PlanWheel XLU2™.

## Scale-Link Includes:

- PlanWheel XLU2™ Scaler
- Ready Connect™ Software
- USB Cable
- Protective Case
- One Year Warranty
- User Manual

## Scale-Link is specially suited for:

- All Windows construction estimating software
- Excel®, Quatro Pro®, Lotus 1-2-3® and other spreadsheets
- Access®, dBase®, Paradox®, Foxpro®, and other databases

## System Requirements

- Windows® Compatible Computer
- CD-ROM Drive
- USB Port

Scale-Link works with all Windows® operating systems.